



LÅSENØKKEL FOR CRONOTEC UR

Merke: Hager

GTIN: 3250612270040

Elnummer: 1480111

Låsenøkkel for Cronotec koblingsur, EG103, EG103D, EG103E, EG103E, EG203, EG203E, EG293B, EG403E, EG493E, EE180, EE181, TX022, TX023

ETIM data:

Type tilbehør/reservedel

Andre

Tilbehør

Ja

Reservedel

Ja

EG004

Godkjenninger:

